

The Future Sonics "FS Ear" logo, Spectrum Series™, ComfortFit™, EarFills™, SofterWear™, Ear Monitors® brand, all associated logos, images and likenesses are trademarks of Future Sonics Incorporated. All other trademarks are property of their respective owners.

Future Sonics Incorporated  
416 Green Lane • Suite 2  
Bristol, Pennsylvania 19007 USA  
www.FutureSonics.com

Copyright © 2015 Future Sonics Incorporated. All rights reserved.  
Future Sonics supports lawful use of technology and does not endorse or encourage the use of our products for purposes other than those designated herein or by law.

The information in this document is subject to change without notice.

15

Spectrum Series™  
Model G10

Professional  
Personal Monitors



ROHS/WEEE

**DOC Statement** (Canada Only)

This Class B digital apparatus complies with Canadian ICES-003.

**Disposal of Waste Equipment**

**by Users in Private Households in the European Union** (European Union Only)

This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service, or the shop where you purchased the product.

**EMI Statement** (European Union Only)

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

16

**NOTE:** The only warranties for Future Sonics products and services are set forth in the warranty statements accompanying our products and services. None of the information or content herein should be interpreted as constituting any additional warranty. Future Sonics shall not be liable for technical or editorial errors or omissions contained herein.

2

**THANK YOU FOR CHOOSING FUTURE SONICS**

We want to hear from you...

For more than three decades, Future Sonics has developed only the finest quality products in professional audio and hearing from you is one of the ways that helps us to continue.

Please let us know your thoughts about our Spectrum Series™ Model G10 professional personal monitors.

3

## TROUBLESHOOTING

### IF YOU NOTICE . . .

Not enough bass response

### SOLUTION

Try different sleeve sizes for best fit and proper coupling in the ear canal. This is essential to achieve the best possible audio quality. Be certain the depth into your ear canal is adequate.

Not staying in place in your ears

Adjust the position of the sleeve on the nozzle by gently rotating it away from the base ( $\pm 1/8$  inch) to adjust its length and fitting position.

Difficulty inserting the foam sleeves into your ears

Compress the foam sleeve evenly on all sides by rolling it between your thumb and index finger; then insert it into your ear canal. Also, try different sleeve types and sizes until you find your best fit option.

Audio levels are too low

Check the sensitivity of your listening device and/or master output level of the audio source.

Only hearing out of one side

Check to see that connector is completely inserted into the jack and the left/right pan settings of your listening device.

Muffled sound, less clarity

Use the loop cleaning tool to check and clear the nozzle opening. Check the sleeves, as well. Remove cerumen (ear wax) or other debris with a gentle outward rotating motion.

**NOTE:** If the earpieces feel either too loose or if they will not insert easily, or if any discomfort occurs once they are in your ears, there is no need for concern. Simply replace the sleeves with the next size or with the other type included in this package.

**Future Sonics does not recommend the use of third-party sleeves.**

18

## CONTACT US

Visit us online for more information: [www.FutureSonics.com](http://www.FutureSonics.com) or call us toll-free at (877) 374-3277

Follow us: **FutureSonics**



**BEST FIT FIRST™ A proper fit is essential to enjoying the full listening benefit from your Spectrum Series™ Model G10 professional monitors.**

a. Choose one size and style from the included fitting options and install it onto your new G10 personal monitors.

b. Using the methods (see item 3), below, insert them into your ears and be sure that you have a good seal and a comfortable fit.

c. You will know when you achieve the best possible fit when you discover the reduction of external sound interference and hear the optimal dynamic range including Future Sonics' signature deep bass response. If you do not experience this sound isolation and bass extension, simply try another one of the fitting options until you achieve your best results.

## TO CHANGE FITTING OPTIONS

a. With the nozzle facing you, use one hand to place your index finger underneath the G10 and your thumb on the flat part at the base of the nozzle.

b. Gently rotate and slide the existing sleeve off the nozzle to remove it.

c. To install a new sleeve, insert the sleeve onto the nozzle and gently rotate until it reaches the flare point above the base. Never force the sleeves **on to or off of the nozzle.**

4

5

## 6 PUTTING YOUR G10 PERSONAL MONITORS IN YOUR EARS

You will find the "left" and "right" side indicators on the interior of the top of the cable's strain relief with the appropriate "L" or "R" embossments.

Spectrum Series™ Model G10 personal monitors are also designed with thumb indents that correspond with the "L" and "R" indicators for ease-of-use in low lighting or darker conditions.

### LISTENING

With the volume OFF on your wireless or wired headphone amp, media player, or other listening device, gradually increase the output audio level to a comfortable listening level.

a. When using **ComfortFit™ foam sleeves**, gently press the foam in towards the nozzle on all sides using your thumb and index finger until the compression is even.

b. Insert each of your G10 personal monitors into your ear canals. Hold the monitor in place for up to 7 seconds until the foam expands and fills the canal creating a good seal.

c. When using **EarFills™ silicone sleeves**, insert each earpiece into the appropriate ear canal and gently rotate them slightly until you achieve a good seal. Again, you will recognize this with the dramatic reduction of all ambient sounds and you hear the maximum bass response.

### Compatibility

Future Sonics Spectrum Series™ model G10 personal monitors are compatible with all standard 1/8" stereo output devices including, but not limited to, professional wireless monitoring systems, hard-wired headphone/earphone amplifiers, personal audio/multimedia players, smartphones, tablets, commercial and consumer communication devices (Some two-way radio devices may require use of an adapter – available from Future Sonics).

### WARRANTY

Future Sonics hereby warrants that this product is without defect in materials, workmanship and/or manufacture for a period of one (1) year from the original date of purchase from an authorized dealer, retailer, or licensed reseller.

This warranty includes housing assembly, casing, and original parts. Future Sonics will, at its option, repair or replace any defective product within the term of this warranty when the original product is returned with its original proof of purchase (required).

This warranty does not apply to any product or part thereof damaged through alteration, mishandling, misuse, neglect, or accident.

This warranty is in lieu of all other warranties, expressed or implied, and no person or representative is authorized to assume for the company any other liability in connection with the sale of this product.

This warranty gives you specific legal rights and you may have other rights that vary from state to state.

## 11 MAINTENANCE

Replace foam and silicon sleeves regularly for optimal performance and cleanliness.

Additional or replacement Future Sonics ComfortFit™ and EarFills™ sleeves are available for purchase directly from our website or from our authorized Future Sonics dealers.

You may also upgrade to longer lasting custom-fit SofterWear™ molded sleeves or Ear Monitors® brand personal monitors. Contact us for details.

## 12 PRODUCT CARE

To keep them looking and sounding their best, be sure to keep your Spectrum Series™ G10 monitors in the carrying case.

Wipe off any dirt, sweat, or cerumen (ear wax) with a clean, dry, lint-free cloth after each use.

Do not use any alcohol based chemicals or cleaning solutions on your monitors.

Do not submerge them in liquids of any kind.

## 13 IMPORTANT WARNINGS

Extreme volume and/or prolonged exposure from elevated sound pressure levels (SPL) can cause serious, permanent damage to your ears and hearing. For best results and optimum safety, we recommend that you adjust your earphones to the lowest volume at which you can comfortably hear the audio output.

Always turn volume down before connecting earphones to your amplifier and/or before inserting earphones into your ears.

Do not use earphones in environments where a failure to hear sounds could be dangerous, such as, but not limited to, while driving a car, operating machinery, or while biking or walking on roadways.

**NOTE: This product includes small parts and cables that may create a choking hazard. Keep away from small children.**

Consult regularly with a physician, audiologist, or hearing specialist if you have problems hearing, develop excessive wax build-up or develop any discomfort after use.

**NOTE: Future Sonics Spectrum Series™ personal monitors may not require the volume of other similar products to provide the best possible sound. This is both safer for the listener and may extend the battery life of some listening devices.**

